


Report for:

Mr. Quality Control
EMLab P&K (QA)
1150 Bayhill Drive
Suite 100
San Bruno, CA 94066

Regarding: Project: Sample Report
EML ID: 1014146

Approved by:

Dates of Analysis:
Spore trap analysis: 01-11-2013



Technical Manager
Murali Putty

Service SOPs: Spore trap analysis (EM-MY-S-1038)
AIHA-LAP, LLC accredited service, Lab ID #102856

All samples were received in acceptable condition unless noted in the Report Comments portion in the body of the report. Due to the nature of the analyses performed, field blank correction of results is not applied. The results relate only to the samples as received. Sample air volume is supplied by the client.

Eurofins EMLab P&K ("the Company") shall have no liability to the client or the client's customer with respect to decisions or recommendations made, actions taken or courses of conduct implemented by either the client or the client's customer as a result of or based upon the Test Results. In no event shall the Company be liable to the client with respect to the Test Results except for the Company's own willful misconduct or gross negligence nor shall the Company be liable for incidental or consequential damages or lost profits or revenues to the fullest extent such liability may be disclaimed by law, even if the Company has been advised of the possibility of such damages, lost profits or lost revenues. In no event shall the Company's liability with respect to the Test Results exceed the amount paid to the Company by the client therefor.

Eurofins EMLab P&K's LabServe® reporting system includes automated fail-safes to ensure that all AIHA-LAP, LLC quality requirements are met and notifications are added to reports when any quality steps remain pending.

Client: EMLab P&K (QA)
C/O: Mr. Quality Control
Re: Sample ReportDate of Sampling: 01-11-2013
Date of Receipt: 01-11-2013
Date of Report: 01-11-2013**SPORE TRAP REPORT: NON-VIABLE METHODOLOGY**

Location:	1: Outside Reference		2		3	
Comments (see below)	None		None		None	
Lab ID-Version‡:	4537964-1		4537965-1		4537966-1	
Analysis Date:	01/11/2013		01/11/2013		01/11/2013	
	raw ct.	spores/m ³	raw ct.	spores/m ³	raw ct.	spores/m ³
Alternaria	1	13			1	13
Ascospores	6	320	1	53	1	53
Basidiospores	14	750	2	110	4	210
Botrytis	2	27				
Chaetomium			2	27		
Cladosporium	22	1,200	47	2,500	9	480
Epicoccum	1	13				
Fusarium	1	13				
Nigrospora						
Other colorless						
Penicillium/Aspergillus types†	12	640	39	2,100	11	590
Pithomyces						
Pyricularia	1	13				
Rusts	1	13				
Smuts, Periconia, Myxomycetes	3	40	1	13	3	40
Stachybotrys			4	53		
Stemphylium						
Torula						
Ulocladium	1	13				
Zygomycetes						
Background debris (1-4+)††	2+		2+		2+	
Hyphal fragments/m ³	40		200		27	
Pollen/m ³	200		13		< 13	
Skin cells (1-4+)	< 1+		< 1+		< 1+	
Sample volume (liters)	75		75		75	
§ TOTAL SPORES/m³		3,000		4,800		1,400

Comments:

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

† The spores of *Aspergillus* and *Penicillium* (and others such as *Acremonium*, *Paecilomyces*) are small and round with very few distinguishing characteristics. They cannot be differentiated by non-viable sampling methods. Also, some species with very small spores are easily missed, and may be undercounted.

†† Background debris indicates the amount of non-biological particulate matter present on the trace (dust in the air) and the resulting visibility for the analyst. It is rated from 1+ (low) to 4+ (high). Counts from areas with 4+ background debris should be regarded as minimal counts and may be higher than reported. It is important to account for samples volumes when evaluating dust levels.

The analytical sensitivity is the spores/m³ divided by the raw count, expressed in spores/m³. The limit of detection is the analytical sensitivity (in spores/m³) multiplied by the sample volume (in liters) divided by 1000 liters.

For more information regarding analytical sensitivity, please contact QA by calling the laboratory.

‡ A "Version" indicated by "-x" after the Lab ID# with a value greater than 1 indicates a sample with amended data. The revision number is reflected by the value of "x".

§ Total Spores/m³ has been rounded to two significant figures to reflect analytical precision.